


Quick Flexhose Disconnect (QFD)

Quick Flexhose Disconnects are an easy way of connecting flexhose to hood collar or duct run. Installs in flexhose with hose clamp. Just unsnap to remove quickly. Collars are built of 20 gauge steel, with zinc plated hardware Priced as a set. Also available separately Male (QFD-M) or Female (QFD-F), call for pricing and availability.



Hose & Blastgate not included.

Dia.	Part No.
4"	04QFD
5"	05QFD
6"	06QFD
8"	08QFD
10"	10QFD
12"	12QFD